Sync® Wireless Earmuff Quick Start Guide



Bluetooth software 4.1, profiles supported:

- HFP 1.6 (Hands Free Profile)
- HSP 1.2 (Headset Profile)
- A2DP 1.2 (Advanced Audio Distribution Profile)
- AVRCP 1.4 (Audio Video Remote Control Profile)

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Honeywell Safety Products USA, Inc. is under license. Other trademarks and trade names are those of their respective owners."

LED DESCRIPTION BLUE: Active Phone Call 1 LED LOGO **GREEN:** Paired. Streaming

RED: Connectable (not-paired)

| FEATURES | DESCRIPTION |
|-------------------|---|
| 2 POWER BUTTON | Power On/OffPairing Mode |

- **VOLUME CONTROL KNOB**
- Previous Song **PREVIOUS BUTTON** • Rewind (if supported) • Reject Incoming Call • Mute/Unmute Mic (during call)
- Next Song **BUTTON** • Fast Forward (if supported) • Reject Incoming Call • Mute/Unmute Mic (during call) • Play / Pause **BUTTON** Accept/End Call Cancel Dialing • Redial Last Number
- AUX (3.5MM) INPUT JACK
- **USB CHARGING PORT** for lithium ion battery
- **BOOM MIC**

NEXT

• Pivot Flex Boom Microphone with Windsock

Please charge fully before first use.

QUICK START

- Turn Bluetooth* on (device)
- Hold Power button on earmuff until LED blinks blue/red (if earmuff already on, double press power button until LED blinks)
- Select "Sync Wireless" from available devices (or "SCAN" if not listed)
- If device requests a PIN please use 0000
- LED will turn green once paired

TROUBLESHOOTING TIP:

Bluetooth performance can be impacted by several factors including: environmental surroundings such as walls, other wireless devices, and distance from paired device. Make sure no other Bluetooth devices are in range while pairing, to ensure no intruder pairs to the earmuff device.

